ASSEMBLE INSTRUCTION

A x28	B x28	C M6x30mm x4	D M8x25mm x4	E x2
F M6x18mm x4	G 5# x1	H 3.5x35mm x8	I 3.5x15mm x42	J x2
K x4	L x4	Spare Parts x1	Spare Parts x1	Spare Parts M6x30mm x1
Spare Parts M8x25mm x1	Spare Parts M6x18mm x1	Spare Parts 3.5x35mm x1	Spare Parts 3.5x15mm x1	

ASSEMBLE INSTRUCTION

STEP 1

G
D
L

STEP 2

G
C
F
⑦

STEP 3

③
B
④
A
⑤
③

STEP 4

A
B
①
I
⑥
②
E

Fix the bottom of the bouncer first, then mounting the
bouncer on it, Rebounder distance is adjustable.

STEP 5

I
A
B
H
⑩
⑩
②
⑦

Measure the diagonal distance before
installing the back panel to ensure
the cabinet is square

ASSEMBLE INSTRUCTION

STEP 6

A

B

H

J

Install it at suitable place .

⑦ ① ② ⑧

⑨ ⑨

K

I

These two screws can adjust the front and rear of the cabinet door and the gap